

Honeywell Galaxy Alarm Panel



- ✓ **Panel Dialler wiring**
- ✓ **Panel Dialler programming**


Background:

Permaconn communicators have a terminal block for the connection of the female 611 fly lead (supplied). If the Alarm Panel also has a terminal block for PSTN connection, we recommend you use your own cable between the Alarm Panel dialler and the Permaconn communicator. This type of installation negates the use of the female 611 fly lead, decreasing your installation time. For four (4), six (6) and eight (8) pin RJ connectors, please refer to manufactures wiring diagram.

There are five (5) minimum requirements from the Alarm panel for successful communication:

- 1) Must have an eight (8) digit primary phone. E.g. 12345678.
- 2) A four (4) digit account number.
- 3) Must be Contact ID format.
- 4) Must be set for tone (DTMF) dialling.
- 5) Open / Close reporting, must be enabled for Pocket Secure App.

Dialler Lead wiring between Permaconn and Honeywell Galaxy series Alarm Panel:



- Enter Engineering Mode.
- Select Menu 56-1 Internal Telecoms.
- 01 Format = Must be 4 (Contact ID).
- 02 Tel N# = enter 12345678
- 03 Acc N# = enter Client ID.
- 04 Receiver = Must be 1 (Single).
- 06 Dial Type = Must be 1 (Tone).
- Exit Engineering Mode.