



CATEGORY	EVENT ID	PARTITION DIALLER	ON IP	ZONE (Unique)	DESCRIPTION
SYSTEM TROUBLE	313	39	00	(Unique) 953 / 954	Engineering Reset (changed encryption key) No action required
	337	39	00	950	Expansion Module DC Loss 3.8V DC voltage low or absent
	350	39	00	953	Failed to Communicate The SafeDial Wireless unit is experienced trouble sending signals and does not expect a restore.
	352	39	00	955 / 956	Permaconn Dialler Lead Fail Fix Issue with the dialler lead between the SafeDial Wireless unit and the Alarm Panel (4 wire interface)
	356	39	00	968	Permaconn IP Path Poll Fail The SafeDial Wireless unit failed its poll requests via IP.
	356	39	00	969	Cellular Network Path Poll Fail The SafeDial Wireless unit failed its poll requests via the cellular network
	356	39	00	970	Permaconn is offline The SafeDial Wireless unit is not responding to network requests
GENERAL ALARMS	140	39	00	981	Auxiliary 1 Auxiliary input on SafeDial Wireless unit
	140	39	00	982	Auxiliary 2 Auxiliary input on SafeDial Wireless unit
	140	39	00	983	Auxiliary 3 Auxiliary input on SafeDial Wireless unit

For more information and FAQ's on any of our Products or services, please visit us online at www.globewireless.com.au

