

Creating a Pocket Secure User

- 1 Go to **<https://safedial.permaconn.com>** on your PC, tablet or smartphone and login using your assigned SafeDial Toolbox/ ATLAS user details.
- 2 Select the **USERS** tab, then click on the green **CREATE USER** button.
- 3 Enter the details of the end-user you wish to set up for Pocket Secure.

Note: The email address you use cannot be the same as an existing login for **SafeDial Toolbox (ATLAS)**.

Enter the following details:

- **First Name** of the End User
- **Last Name** of the End User
- **Email Address** of the End User
- **Mobile Number** of the End User
- **Password & Confirmation of Password**
- **Role** - Choose "**Pocket Secure End User**" from the dropdown menu





Once all information is entered correctly, click **CREATE USER** to add the customer details.

- 4 You will then be prompted to add the SafeDial unit the end-user requires access to Arm/Disarm. Begin typing the serial number or the unit name into the text field at the top of the window and select the device from the drop-down list.

Multiple units can be added and will appear in this window once selected.

- 5 Once all unit are added, select **OK**.
- 6 **POCKET SECURE SETUP IS COMPLETE**

Note: An ARM & DISARM MUST be sent for Pocket Secure to work.



Customer Download - Pocket Secure App

Your customer will receive a text message to the registered mobile number confirming their login details, along with a link to download the Pocket Secure App from their Application Store.

The user will then be prompted for their email address and password upon successfully opening Pocket Secure.